


Quick Start Guide - Android Player

2022.Q2



Player Installation, Activation and Registration



Android Player Installation

1. Download client file at
<https://download.wise-apps.com/>

ADVANTECH Document

Download Search



Solution Category	File Name	Size	Date
+ Infection Prevention Solution	☐ IDS.SignageCMS_Android-V2.5.0.0-A6.zip	7,768.9 KB	2022-09-16 23:44:10
+ Video AI Facial Recognition	☐ IDS.SignageCMS_Client_Win10-v2.5.0.0.zip	134,868.5 KB	2022-09-16 23:44:46
- WISE-PaaS SignageCMS	☐ IDS.SignageCMS_Server_Win10-v2.5.0.1.zip	435,554.8 KB	2022-09-16 23:46:23
API Document			
Official Software			
Plug-in			
+ WISE-PaaS Store BI			

2. Copy files to USB drive(FAT32), then plug it to Signage Player.





Android Player Installation

3. Open explorer, install Edge_PSAdmin apk file first, then install Edge_PSClient apk file.




4. Open PSClient in apps, then allow the permission.




Android Player Setting

1. The screen will show when system startup.




2. Change location to current location in setting page.




Android Player Setting

3. Change data, time, then turn off sunlight saving time.

✘ Incorrect setting will effect signage schedule.




4. Change Language.(Optional)




Android Player Setting

5. Press SiganceCMS icon to main program, then move the mouse cursor to left side, press mouse left button and hold, drag the cursor to right side, click client setup.



6. Click “WISE-iService – Public Cloud” of Server to change other server type.



Server

SignageCMS Server

Client ID

C400AD165D0D

Hostname / IP

☐ HTTPS

Please enter the server IP or host name.

Port

80

1883

General Setup

☒ Auto Restart Signage Client

☒ Accessibility Service (Client Installation, Kiosk Mode)

☒ Device Administration

☐ Disable Slide Menu (Dragging)

☐ Enable Web Input

☒ Enable Interaction

Interaction Key

0000

Engineering Password

Manage Storage

☐ Allocate schedule to portable storage, e.g. USB drive, SD card. Notice! Please restart client after hot plugging of portable storage.

CANCEL

SAVE

Android Player Setting

7. Click SignageCMS Server.

StoreVue

WISE-iService - Public Cloud

WISE-iService - Private Cloud

SignageCMS Server

8. Input Server IP, then check the box as below figure to make sure permission have been accepted.

Server
SignageCMS Server

Client ID
C400AD165D0D

☐ HTTPS
Please enter the server IP or host name.

Port
80
1883

General Setup

- ☒ Auto Restart Signage Client
- ☒ Accessibility Service (Silent Installation, Kiosk Mode)
- ☒ Device Administration
- ☐ Disable Slide Menu (Dragging)
- ☐ Enable Web Input
- ☒ Enable Interaction

Interaction Key
0000

Engineering Password


Manage Storage
☐ Allocate schedule to portable storage, e.g. USB drive, SD card. Notice! Please restart client after hot plugging of portable storage.

CANCEL


SAVE

Android Player Registration

1. Input SignageCMS server IP address via browser.
Default user/password:admin/admin




2. Click gear icon, then select Client Device.




Android Player Registration

3. Click New button to add player.



4. Input Name & Client ID data to new device of server , then press Save & Exit button.



Android Player Registration

5. Now, you can see the new device has been added.

iDS.SignageCMS

Media

Program

Schedule

Script

Dispatch

⚙

Player

All

Export

Reload

Power On

Power Off

Restart

Upgrade

New

Remove

Device List

Group

Batch Setup

Power Schedule Overview

Online status	Device	Dispatch Time	DispatchContent	Play	Department
✔	Android Player v2.5.0.0-Edge	View Edit 🕒	📅	📅	admin

Selected: 0

Online: 1

Offline: 0

Co-Creating the Future of the IoT World

